

目录

Australia UHF CB Radio Channel	3
Notes	4

Australia UHF CB Radio Channel

Channel	Frequency (MHz)	Use	Comments
1	476.4250	Duplex - Repeater Output	
2	476.4500	Duplex - Repeater Output	
3	476.4750	Duplex - Repeater Output	
4	476.5000	Duplex - Repeater Output	
5	476.5250	Duplex - Repeater Output	Emergency use only
6	476.5500	Duplex - Repeater Output	
7	476.5750	Duplex - Repeater Output	
8	476.6000	Duplex - Repeater Output	
9	476.6250	Simplex	
10	476.6500	Simplex	4WD Drivers - Convoy, Clubs & National Parks
11	476.6750	Simplex	Call Channel
12	476.7000	Simplex	
13	476.7250	Simplex	
14	476.7500	Simplex	
15	476.7750	Simplex	
16	476.8000	Simplex	
17	476.8250	Simplex	
18	476.8500	Simplex	Caravan & Campers Convoy Channel
19	476.8750	Simplex	
20	476.9000	Simplex	
21	476.9250	Simplex	
24	477.0000	Simplex	
25	477.0250	Simplex	
26	477.0500	Simplex	
27	477.0750	Simplex	
28	477.1000	Simplex	
29	477.1250	Simplex	Pacific Hwy (NSW) & Bruce Hwy (Qld) Road Channel
30	477.1500	Simplex	UHF CB Broadcasts
31	477.1750	Repeater Input	
32	477.2000	Repeater Input	
33	477.2250	Repeater Input	
34	477.2500	Repeater Input	
35	477.2750	Repeater Input	Emergency Use Only
36	477.3000	Repeater Input	
37	477.3250	Repeater Input	
38	477.3500	Repeater Input	
39	477.3750	Simplex	
40	477.4000	Simplex	Highway Channel
41	476.4375	Duplex - Repeater Output	
42	476.4625	Duplex - Repeater Output	
43	476.4875	Duplex - Repeater Output	

Channel	Frequency (MHz)	Use	Comments
44	476.5125	Duplex - Repeater Output	
45	476.5375	Duplex - Repeater Output	
46	476.5625	Duplex - Repeater Output	
47	476.5875	Duplex - Repeater Output	
48	476.6125	Duplex - Repeater Output	
49	476.6375	Simplex	
50	476.6625	Simplex	
51	476.6875	Simplex	
52	476.7125	Simplex	
53	476.7375	Simplex	
54	476.7625	Simplex	
55	476.7875	Simplex	
56	476.8125	Simplex	
57	476.8375	Simplex	
58	476.8625	Simplex	
59	476.8875	Simplex	
60	476.9125	Simplex	
64	477.0125	Simplex	
65	477.0375	Simplex	
66	477.0625	Simplex	
67	477.0875	Simplex	
68	477.1125	Simplex	
69	477.1375	Simplex	
70	477.1625	Simplex	
71	477.1875	Repeater Input	
72	477.2125	Repeater Input	
73	477.2375	Repeater Input	
74	477.2625	Repeater Input	
75	477.2875	Repeater Input	
76	477.3125	Repeater Input	
77	477.3375	Repeater Input	
78	477.3625	Repeater Input	
79	477.3875	Simplex	
80	477.4125	Simplex	

Notes

- If you switch on DUPLEX at Channel 1 to 8, 41 to 48, then your radio will receive signal from these channels but send at Channel 31 to 38, 71 to 78 to repeaters nearby, and the repeaters will send signal at the original channel. So do not use channel 31 to 38, 71 to 78 directly with simplex mode.
- Channel 5 and 35 is for **Emergency use only!**
- General conversation channels: 9, 10, 12-21, 24-30, 39, 49-60, 64-70, 79, 89.

From:

<https://irdya.top/> - 漂流記

Permanent link:

https://irdya.top/en/misc/australia_uhf_cb

Last update: **2022/05/26 03:24**

